



*All dimensions shown in red are based on a suggested mounting height (see measurement to UNDERSIDE of down-tube on far left). For specific applications and environments, the mounting bracket should be installed at a height so that, when fitted, the lighthead is as near to the required position as possible. Actual location should be dependent on intended use and desired reach. Common sense should always prevail.